

* ADD TWO M6 WASHERS BETWEEN [R] BASE PLATE AND COLLAR 9, COLLAR 22 AND STOCK GASKET FOR '08 MODEL.



