




[R]



[L]



(BACK)



1. (L) HEEL GUARD [HG-17L]
2. (R) HEEL GUARD [HG-22R]
3. (L) STEP PLATE [BMW-R9TRASP-L]
4. (R) STEP PLATE [BMW-R9TRASP-R]
5. MASTER STAY [BMW-R9TRAMS]
6. SHIFT PEDAL [SPD-SCP70]
7. SHIFT ARM (BK) [CA-7]
8. SHIFT ROD 40 [SRD-40]
9. BRAKE PEDAL [BPD-165-30]
10. FOOT PEG [PEG] x 2
11. FOOT PEG END CAP [ST-002] x 2
12. PEDAL TIP (DELRIN) [ST-001D18] x 2
13. ROD END COLLAR 10 (BK) [RDED-CLR10]
14. BASE PLATE COLLAR 5 (BK) [BPCLR-5] x 4
15. SHIFT SPINDLE SPACER (BK) [BMW-R9T-SHSS]
16. BEARING COLLAR 13 (BK) [PEGBGCLR-13SB]
17. PEG COLLAR 15 [PEGCLR-15] x 2
18. PEDAL STOPPER (DELRIN) [BPD-STOPPER]
19. SOCKET HEAD M5 x 25mm [BBT-M525]
20. SOCKET HEAD M8 x 25mm [SBT-M825] x 4
21. BUTTON HEAD M5 x 35mm [BBT-M535]
22. BUTTON HEAD M6 x 10mm [BBT-M610] x 4
23. BUTTON HEAD M6 x 20mm [BBT-M620] x 2
24. BUTTON HEAD M6 x 25mm [BBT-M625] x 2
25. BUTTON HEAD M6 x 35mm [BBT-M635]
26. BUTTON HEAD M8 x 25mm [BBT-M825]
27. BUTTON HEAD M8 x 40mm [BBT-M840]
28. HEX HEAD M6 x 18mm x 2
29. FLANGE HEAD M6 x 20mm [FGBT-M620]
30. STUD M6 x 35mm [STUD-M6-35]
31. STUD BOLT M8 x 50mm [STBT-50] x 2
32. NUT M5 [NUT-5] x 2
33. JAM NUT M6 [JNT-6] x 2
34. REVERSE JAM NUT M6 [JNT-6L]
35. LOCK NUT M6 [LNT-6]
36. FLANGE NUT M8 [FNT-6] x 2
37. WASHER M5 [WS-5] x 2
38. FEMALE ROD END M6 [RDED-F6] x 2
39. REVERSE MALE ROD END M6 [RDED-M6L]
40. RETURN SPRING COLLAR b [RS-RSCLR2]
41. RETURN SPRING 20 [RS-RSP2]
42. SPRING SEAT M6 [NUT-SPS6]
43. MICROSWITCH [BSW-MICRO]
44. SWITCH BASE [BMW-R9TSB]
45. NUT (BMW PARTS) x 2