


Flat side of **BEARING COLLAR 10** (#15) should face the **STEP PLATE** (#3), with the stepped side facing out towards the shift pedal bearings.



1. (L) HEEL GUARD [HG-2L]
3. (L) STEP PLATE [K-ZX613SP-L]
5. (L) BASE PLATE [K-ZX613BP-L]
7. SHIFT PEDAL [SPD-SCP70]
11. FOOT PEG [PEG]
12. FOOT PEG END CAP [ST-002]
13. PEDAL TIP (DELRIN) [ST-001D18]
15. BEARING COLLAR 10 (BK) [PEGBGCLR-10SB]
16. PEG COLLAR 12 [PEGCLR-12]
18. REVERSE STUD M6 [STUD-M6L]
21. HEX HEAD M6 x 18mm [HBT-M618]
22. HEX HEAD M8 x 40mm [HBT-M840]
24. LOW SOCKET HEAD M6 x 20mm [LSBT-M620]
25. LOW SOCKET HEAD M8 x 15mm [LSBT-M815] x 2
26. BUTTON HEAD M6 x 10mm [BBT-M610] x 2
28. BUTTON HEAD M8 x 35mm [BBT-M835]
31. REVERSE JAM NUT M6 [JNT-6L] x 2
35. SPLIT WASHER M8 [SWS-8]
36. REVERSE FEMALE ROD END M6 [RDED-F6L]

PEG POSITIONS

	0mm Back	20mm Up
1		
2		
3		
4		
5		
6*		
7*		
8*		

All measurements are in relation to stock foot peg position (0 mm).

* Positions 1-5 are compatible with the stock brake light pull switch. Positions 6-8 requires using a pressure-type brake light switch (part# BSW-125) (sold separately)