



[L]



[R]



1. (R) SLIDER PUCK [SDR-L10MFJ]
2. (L) SLIDER PUCK [SDR-L10-85MFJ]
3. (R) SLIDER BASE OUTER
4. (L) SLIDER BASE OUTER
5. (R) SLIDER BASE INNER (BK)
6. (L) SLIDER BASE INNER (BK)
7. COLLAR 10-6 [CLR-10-6]
8. COLLAR 15-6 [CLR-15-6]
9. COLLAR 20-10 [CLR-20-10]
10. COLLAR 7.5-10 [CLR-75-10]
11. COLLAR 10-10 [CLR-10-10]
12. COLLAR 13-10 [CLR-13-10]
13. COLLAR 15-10S [CLR-15-10S]
14. COLLAR 25-10S [CLR-25-10S]
15. SOCKET HEAD M6×25 [SBT-M625]
16. SOCKET HEAD M6×30 [SBT-M630]
17. SOCKET HEAD M10×50 (P-1.25) [SBT-M1050]
18. SOCKET HEAD M10×55 (P-1.25) [SBT-M1055]
19. SOCKET HEAD M10×70 (P-1.25) [SBT-M1070]
20. SOCKET HEAD M10×75 (P-1.25) [SBT-M1075] (Qty:2)
21. SOCKET HEAD M10×80 (P-1.25) [SBT-M1080]
22. WASHER M10 [ws-10] (Qty:2)
- 23. WASHER (STOCK YAMAHA PART) (Qty:3)**