



[L]



[R]



1. (L) HEEL GUARD [HG-6L]
2. (R) HEEL GUARD [HG-6R]
3. (L) STEP PLATE [H-CBR120SP-L]
4. (R) STEP PLATE [H-CBR120SP-R]
5. (L) BASE PLATE [H-CBR120BP-L]
6. (R) BASE PLATE [H-CBR120BP-R]
7. SHIFT PEDAL [SPD-CPB014]
8. SHIFT PEDAL BASE [SPD-CPB013]
9. BRAKE PEDAL [BPD-BPSS165]
10. STAY (BK) [STAY-60645T6]
11. FOOT PEG [PEG] x 2
12. FOOT PEG END CAP [ST-002] x 2
13. PEDAL TIP (DELFIN) [ST-001D18] x 2
14. FOOT PEG COLLAR 15 [PEGCLR-15] x 2
15. BEARING COLLAR 5 (BK) [PEGBGCLR-5SB]
16. SPACER COLLAR (Pre-installed In Shift Pedal Base)
17. ROD END COLLAR 29 (BK) [RDED-CLR29]
18. COLLAR 18-8 (BK) [CLR-18-8]
19. SOCKET HEAD M5 x 15mm [SBT-M515]
20. SOCKET HEAD M5 x 40mm [SBT-M540]
21. SOCKET HEAD M6 x 18mm [SBT-M618]
22. SOCKET HEAD M6 x 55mm [SBT-M655]
23. SOCKET HEAD M8 x 50mm [SBT-M850]
24. NARROW SOCKET HEAD M6 x 15mm [SBT-M615S] x 2
25. LOW SOCKET HEAD M6 x 20mm [LSBT-M620] x 2
26. LOW SOCKET HEAD M8 x 15mm [LSBT-M815] x 4
27. LOW SOCKET HEAD M8 x 20mm [LSBT-M820] x 4
28. BUTTON HEAD M6 x 10mm [BBT-M610] x 4
29. BUTTON HEAD M6 x 25mm [BBT-M625] x 2
30. BUTTON HEAD M8 x 30mm [BBT-M830]
31. HEX HEAD M5 x 6mm [HBT-M56]
32. HEX HEAD M8 x 40mm [HBT-M840] x 2
33. SPLIT WASHER M8 [SWS-8] x 2
34. NUT M5 [NUT-5]
35. LOCK NUT M6 [LNT-6]
36. FEMALE ROD END 6-M8 [RDED-F6-8]
37. PULL SWITCH STAY 14 [PSTAY-14]
38. RETURN SPRING 8-25 [RS-RSP-825]

***39. NUT (HONDA PART)**

***40. PULL SWITCH (HONDA PART)**

Make sure there is no interference between the brake hose and seat rail / frame.

Back Side

