



- | | | |
|---|--|--|
| <p>1. [L] HEEL GUARD [HG-2L]
2. [R] HEEL GUARD [HG-1R]
3. (L) BASE PLATE
4. (R) BASE PLATE
5. SHIFT PEDAL [SPD-10]
6. SHIFT ROD 180 [SRD-180]
7. V LINK (BK) [SK-1]
8. BRAKE PEDAL [BPD-19]
9. FOOT PEG (x2) [PEG]
10. FOOT PEG END CAP [ST-002] (x2)
11. PEDAL TIP (DELFIN) [ST-001D] (x2)
12. BEARING COLLAR 5s (BK) [PEGBGCLR-5s]
13. BEARING COLLAR 10s (BK) [PEGBGCLR-10s]
14. ROD END COLLAR 3 (GD) [RDED-CLR3]
15. ROD END COLLAR 20 (BK) [RDED-CLR20]</p> | <p>16. BASE PLATE COLLAR 5 (BK) [BPCLR-5] (x4)
17. PEG COLLAR 15 [PEGCLR-15] (x2)
18. SOCKET HEAD M5×15mm [SBT-M515]
19. SOCKET HEAD M5×30mm [SBT-M530]
20. SOCKET HEAD M6×18mm [SBT-M618]
21. SOCKET HEAD M6×20mm [SBT-M620]
22. SOCKET HEAD M6×25mm [SBT-M625]
23. SOCKET HEAD M6×45mm [SBT-M645]
24. SOCKET HEAD M8×25mm [SBT-M825] (x4)
25. SOCKET HEAD M8×40mm [SBT-M840]
26. BUTTON HEAD M6×10mm [BBT-M610] (x2)
27. BUTTON HEAD M6×20mm [BBT-M620] (x2)
28. BUTTON HEAD M6×25mm [BBT-M625] (x2)
29. BUTTON HEAD M8×25mm [BBT-M825]
30. BUTTON HEAD M8×30mm [BBT-M830]</p> | <p>31. HEX BOLT M5×8mm [HBT-M58]
32. HEX BOLT M8×40mm [HBT-M840] (x2)
33. STUD M6 [STUD-M6]
34. SMALL WASHER M8 [PWS-8]
35. SPLIT WASHER M8 [SWS-8] (x2)
36. NUT M5 [NUT-5] (x2)
37. JAM NUT M6 [JNT-6] (x2)
38. REVERSE JAM NUT M6 [JNT-6L]
39. LOCK NUT M6 [LNT-6] (x2)
40. MALE REVERSE ROD END M6 [RDED-M6L]
41. FEMALE ROD END M6 [RDED-F6] (x2)
42. FEMALE ROD END 6-M8 [RDED-F6-8]
43. PULL SWITCH STAY 14 [PSTAY-14]</p> |
|---|--|--|