


Flat side of **BEARING COLLAR 5** (#15) should face **STEP PLATE** (#4), with the stepped side facing out toward the **SHIFT PEDAL** bearings.



1. (L) HEEL GUARD [HG-31L]
2. (L) BOLT COVER [H-GROM16BCR-L]
4. (L) STEP PLATE [H-GROM16SP-L]
6. SHIFT PEDAL [SPD-14]
7. SHIFT ROD 80(BK) [SRD-80B]
11. FOOT PEG [PEG]
12. FOOT PEG END CAP [ST-002]
13. PEDAL TIP (DELFIN) [ST-001D18]
15. BEARING COLLAR 5 (BK) [PEGBGCLR-5SB]
17. ROD END COLLAR 29 (BK) [RDED-CLR29]
19. BASE PLATE COLLAR 5 (BK) [BPCLR-5]
20. COLLAR 10-12 (BK) [CLR-10-12]
22. PEG COLLAR 15 [PEGCLR-15]
23. SOCKET HEAD M5x10mm [SBT-M510]
25. SOCKET HEAD M6x55mm [SBT-M655]
26. SOCKET HEAD M8x20mm [SBT-M820]
28. STUD BOLT M8x55mm [STBT-S]
30. BUTTON HEAD M6x10mm [BBT-M610] x 2
33. BUTTON HEAD M8x30mm [BBT-M830]
34. LOW SOCKET HEAD M6x20mm [LSBT-M620]
36. HEX HEAD M6x18mm [HBT-M618]
40. JAM NUT M6 [JNT-6]
41. REVERSE JAM NUT M6 [JNT-6L]
42. LOCK NUT M6 [LNT-6]
43. FLANGE NUT M8 [FNT-8]
44. MALE ROD END M6 [RDED-M6]
45. REVERSE MALE ROD END M6 [RDED-M6L]

* 47. **CHANGE ARM (STOCK HONDA PART)**

* 48. **WASHER (STOCK HONDA PART)**