





[R]



(back side)



[L]



- | | | | |
|---------------------------------|--------------------------------------|-----------------------------|-------------------------|
| 1. (L) HEEL GUARD [HG-3L] | 11. LONG NUT M6x25mm | 21. SOCKET HEAD M6x35mm x 2 | 31. PEG WASHER M8 |
| 2. (R) HEEL GUARD [HG-23R] | 12. BRAKE PEDAL [BPD-RS4125] | 22. SOCKET HEAD M8x15mm x 8 | 32. SPLIT WASHER M8 x 2 |
| 3. (L) STEP PLATE [Y-MT09SP-L] | 13. MASTER STAY [Y-MT09MS] | 23. SOCKET HEAD M8x45mm | 33. NUT M5 |
| 4. (R) STEP PLATE [Y-MT09SP-R] | 14. FOOT PEG x 2 | 24. BUTTON HEAD M6x10mm x 4 | 34. JAM NUT M6 |
| 5. (L) EXTENSION PLATE(BK) | 15. FOOT PEG END CAP x 2 | 25. BUTTON HEAD M6x18mm | 35. FLANGE NUT M8 |
| 6. (R) EXTENSION PLATE(BK) | 16. PEDAL TIP (DELFIN) [ST-001D] x 2 | 26. BUTTON HEAD M6x20mm x 2 | 36. MALE ROD END M6 |
| 7. (L) BASE PLATE(BK) | 17. ROD END COLLAR 15 (BK) | 27. BUTTON HEAD M8x25mm x 3 | 37. FEMALE ROD END 6-M8 |
| 8. (R) BASE PLATE(BK) | 18. PEG COLLAR 12 x 2 | 28. HEX HEAD M6x30mm | 38. PULL SWITCH STAY 16 |
| 9. SHIFT PEDAL (BK) [SPD-CP016] | 19. BEARING COLLAR 15SB (BK) | 29. HEX HEAD M5x6mm | BRAKE RETURN SPRING 40 |
| 10. SHIFT BASE (BK) [SB-YMT09] | 20. SOCKET HEAD M5x35mm | 30. HEX HEAD M8x40mm x 2 | (Not Pictured) |